

Auto Bolt Fitting Instructions

1. Fit the autobolt cover box to the frame central with the latch and with the front face of the cover box recessed into the frame then remove.
2. Fit the mechanism plate central with the recess and with the front edge to the recess.
3. Close the door and release the latch bolt (L2000) to make contact with the round cam on the mechanism.
4. Rotate the cam in contact with the latch bolt in its fully thrown position to move the autobolts across the door face to the maximum amount.
5. Fix the cam firmly in this position with the allen key provided.
6. Fit the cover box and close the door.
7. Check that the bolts move across the face of the door and that the lock indicator button (L2000) is fully projecting from the face of the latch.
8. Retract the latch bolt and observe that the autobolts return inside the cover box.